



PRODUCT CATALOGUE  
May 2019





## HV2000 SERIES

Prime movers - Heavy duty, off road & highway conditions

The HV2000 is heavy duty adjustable monotube shock absorber ideally suited to heavy trucks and where ultimate performance counts

- ✓ Air/gas adjustability for any road or load
- ✓ Patented piston design prevents aeration
- ✓ Monotube configuration improves responsiveness
- ✓ Separate gas chamber for better cooling
- ✓ Air suspension connectivity
- ✓ Built tough, extended service life

SHOCK TYPE	MONOTUBE
SEALS	VITON 90
BORE SIZE	63MM
SHAFT	25MM HARDENED CHROME
BUSHING	POLYURETHANE
WARRANTY	12 MONTHS / 24 EXTENDED*

\*CONDITIONS APPLY



## HV1000 SERIES

Prime movers - Heavy duty, off road & highway conditions

The HV1000 is an adjustable monotube shock absorber specifically designed for highway and off-road use on heavy trucks

- ✓ Air/Gas adjustability for any road or load
- ✓ Patented piston design prevents aeration
- ✓ Monotube configuration improves responsiveness
- ✓ Air suspension connectivity
- ✓ Built tough, extended service life

SHOCK TYPE	MONOTUBE
SEALS	NBR 70
BORE SIZE	57MM
SHAFT	20MM HARDENED CHROME
BUSHING	RUBBER
WARRANTY	12 MONTHS





## HV500 SERIES

Prime movers, light trucks & trailers - highway conditions

The HV500 is a premium twin-tube suitable for a wide range of prime movers, light trucks and trailers

- ✓ Oversized body for increased oil content
- ✓ One-piece eye rings, 360-degree welds
- ✓ Built tough, long lasting
- ✓ Outperforms OE shock absorbers
- ✓ Great value highway shock

SHOCK TYPE	TWIN TUBE
SEALS	NBR 70
BORE SIZE	50MM
SHAFT	20MM HARDENED CHROME
BUSHING	RUBBER
WARRANTY	12 MONTHS



## CAB SERIES

Prime movers - All conditions

The RedRoo CAB SERIES is an adjustable shock absorber suitable for all cabin applications where comfort counts

- ✓ Patented piston design prevents aeration
- ✓ Air / Gas adjustability for increased comfort
- ✓ Superior dampening of high and low frequency cabin vibration
- ✓ Cabin airbag connectivity for active dampening control
- ✓ Built tough, extended service life

SHOCK TYPE	MONOTUBE
SEALS	VITON 90
BORE SIZE	57MM
SHAFT	20MM HARDENED CHROME
BUSHING	RUBBER
WARRANTY	12 MONTHS





## TABLE OF CONTENTS

Shock Absorber Range .....	2
CAT .....	5
Freightliner .....	5
International .....	6
Iveco .....	6
Kenworth .....	7
Mack .....	8
Volvo .....	9
Western Star .....	9
Trailer .....	10
HV2000 Series Full Shock Packages .....	11
Cab Mount Shocks .....	12
Air Installation Kits .....	13
Cab Shock Bush Kits .....	14
HV2000 Service Kits & Spare Parts .....	14
Shock Absorber Bush Kits .....	15
Shock Absorber Bushes .....	16
Individual Sleeves .....	17



**SHOCK ABSORBER RANGE**

YEAR	MODEL/SUSPENSION TYPE	OME#	HV2000 SERIES	HV1000 SERIES	HV500 SERIES
<b>CAT</b>					
FRONT SUSPENSION					
2013 -	CT6 SERIES - PARABOLIC	3606 859 C2 3674 348 C1	HV2002		
REAR SUSPENSION					
2013 -	HENDRICKSON PRIMAAX	60657-003	HV2010L HV2010R		
<b>FREIGHTLINER</b>					
FRONT SUSPENSION					
N/A	ARGOSY LOWER MOUNTING STUD RUNNING FRONT TO BACK	10-13211-000 10-13634-000 10-13211-000	HV2006	HV1006	HV506
N/A	ARGOSY LOWER MOUNTING STUD RUNNING LEFT TO RIGHT	10-13211-000 10-13634-000 10-13211-000	HV2007	HV1006	HV506
N/A	CENTURY CLASS, COLUMBIA, CORONADO  LOWER MOUNTING STUD RUNNING FRONT TO BACK	10-13021-000 10-13063-000 10-13211-000 10-13634-000 10-13809-000 10-14177-000	HV2008	HV1008	HV508
N/A	CENTURY CLASS, COLUMBIA, CORONADO*  LOWER MOUNTING STUD RUNNING LEFT TO RIGHT *Except Coronado Cummins engine RH Front	10-13021-000 10-13063-000 10-13211-000 10-13634-000 10-13809-000 10-14177-000	HV2009		
N/A	CORONADO RHS CUMMINS ENGINE ONLY  LOWER MOUNTING STUD RUNNING FRONT TO BACK	10-13021-000 10-13063-000 10-13211-000 10-13634-000 10-13809-000 10-14177-000	HV2022		



**SHOCK ABSORBER RANGE**

YEAR	MODEL/SUSPENSION TYPE	OME#	HV2000 SERIES	HV1000 SERIES	HV500 SERIES
<b>FREIGHTLINER (CONTINUED)</b>					
REAR SUSPENSION					
N/A	AIRLINER	16-15817-000 16-13957-000 16-13957-003 16-18708-000 16-20649-000	HV2003L HV2003R	HV1003	HV503
2000 -	NEWAY AD246	3501001 90045504	HV2004L HV2004R	HV1008	
N/A	HENDRICKSON PRIMAAX		HV2010L HV2010R		
<b>INTERNATIONAL</b>					
FRONT SUSPENSION					
N/A	EAGLE (9200, 9900)	3270806R1 358453C1/C2/C3	HV2024		
REAR SUSPENSION					
N/A	NEWAY AD246		HV2004L HV2004R	HV1008	
	HENDRICKSON PRIMAAX	60657-3 60657-003	HV2010L HV2010R		



**SHOCK ABSORBER RANGE**

YEAR	MODEL/SUSPENSION TYPE	OME#	HV2000 SERIES	HV1000 SERIES	HV500 SERIES
<b>IVECO</b>					
FRONT SUSPENSION					
N/A	POWERSTAR 6300/6400/6500/6700 3 LEAF PARABOLIC	97137446	HV2027		
	POWERSTAR 6300/6500/6700/6800 7500/7700 MULTILEAF	97135133 3252043R2	HV2028		
2007	POWERSTAR 485 3 LEAF PARABOLIC	41218445 98414529 99474655	HV2034		
<b>KENWORTH</b>					
FRONT SUSPENSION					
1992 -	K-SERIES	90-2209SP2	HV2011*	HV1011	HV511
	T-SERIES	90-2209SP3			
	MULTILEAF/ PARABOLIC (EXCEPT SOME SAR MODELS)**	K374-11 K374-16 K374-26 K374-27			
<p><i>*NOTE: EARLIER MODELS (UP TO APPROXIMATELY 1999) MAY REQUIRE STEER SHOCK HV2025. IF THE STATIC HEIGHT OF THE SHOCK IS GREATER THAN 590mm, THEN PART HV2025 MUST BE USED. HV511 &amp; HV1011 WILL ONLY SUIT APPLICATIONS WHERE THE STATIC HEIGHT IS LESS THAN 590MM</i></p> <p><i>**NOTE: HV2011 WILL FIT MOST SAR MODELS, HOWEVER THE SHOCK MUST BE FITTED UPSIDE DOWN TO ALLOW CLEARANCE FOR THE SIDE CHAMBER. NOTE THAT SOME NEW SAR MODELS HAVE INSUFFICIENT CLEARANCE FOR SIDE CHAMBER ALTOGETHER. CHECK YOUR SPECIFIC APPLICATION.</i></p>					



**SHOCK ABSORBER RANGE**

YEAR	MODEL/SUSPENSION TYPE	OME#	HV2000 SERIES	HV1000 SERIES	HV500 SERIES
<b>KENWORTH cont.</b>					
<b>REAR SUSPENSION</b>					
N/A	AIRGLIDE 9" (DOUBLE STUDTYPE - SHOCKS MOUNTED OUTSIDE CHASSIS RAIL)	K374-41 90-2477SP1 C71-1012 665903 665944	HV2020		
	AIRGLIDE 10.5" (DOUBLE STUD TYPE - SHOCKS MOUNTED OUTSIDE CHASSIS RAIL)	K374-38 90-2478SP3 90-2478SP4 C71-1006 665906	HV2021	HV1021	HV521
	HENDRICKSON HAS-4 SERIES (EXCEPT INBOARD SHOCK OPT)	60670-005L 47902-24 57905-001	HV2005		
	HENDRICKSON PRIMAAX	60657-003 60657-003L 60657-005 98583-032	HV2010L HV2010R		
2000 -	NEWAY AD246/ 369	3501001	HV2004L HV2004R	HV1008	





## SHOCK ABSORBER RANGE

YEAR	MODEL/SUSPENSION TYPE	OME#	HV2000 SERIES	HV1000 SERIES	HV500 SERIES
<b>MACK</b>					
<b>FRONT SUSPENSION</b>					
N/A	GRANITE, SUPERLINER, TITAN, TRIDENT MULILEAF (LOWER MOUNTING STUD RUNNING FRONT TO BACK)	21010744 14QK-3116M 21155033	HV2026	HV1026	HV526
	METROLINER (LOWER MOUNTING STUD RUNNING FRONT TO BACK)	21010744	HV2032		
	GRANITE, SUPERLINER, TITAN, TRIDENT MULILEAF (LOWER MOUNTING STUD RUNNING LEFT TO RIGHT)	21010744 14QK-3116M 21155033	HV2030	HV1030	HV530
	CHR, CLR, METROLINER, TRIDENT, VALULINER & VISION PARABOLIC (LOWER MOUNTING STUD RUNNING LEFT TO RIGHT)	14QK392BM	HV2030	HV1030	HV530
	TRIDENT PARABOLIC SET BACK FRONT AXLE (STUD BASE/ EYE TOP)	21320856	HV2035		
<b>REAR SUSPENSION</b>					
N/A	HENDRICKSON PRIMAAX (MACK AP460)	60657-3 60657-7 60657-003 60657-007 20782199 21341752 21341754	HV2010L HV2010R		
	HENDRICKSON HAS* (MACK AL460 VERSION)	60670-6 20570098	HV2037		
	HENDRICKSON HAS-4 SERIES* (EXCEPT INBOARD SHOCK OPTION)	60670-005	HV2005		
	MILX STEEL SPRING SUSPENSION	21979345	HV2029		

\* PLEASE ENSURE THERE IS MINIMUM 150mm HORIZONTAL CLEARANCE BETWEEN THE CENTRE OF THE LOWER EYE BOLT (ON THE REAR AXLE SHOCK) AND THE TAILLIGHT BAR. IF THERE IS INSUFFICIENT CLEARANCE, THE SHOCK SIDE CHAMBER MAY FOUL ON THE TAILLIGHT BAR.



## SHOCK ABSORBER RANGE

YEAR	MODEL/SUSPENSION TYPE	OME#	HV2000 SERIES	HV1000 SERIES	HV500 SERIES
<b>VOLVO</b>					
FRONT SUSPENSION					
N/A	CAB OVER MODELS * (EXCEPT FMX MODEL)	20374546 20374548	HV2016 *	HV1016	
*NOTE: HV2000 SHOCK MUST BE FITTED UPSIDE DOWN TO MOST MODELS TO ALLOW CLEARANCE FOR SIDE CHAMBER					

## WESTERN STAR

FRONT SUSPENSION					
N/A	ALL MODELS* WITH: PARABOLIC/ MULTILEAF  (LOWER STUD RUNNING LEFT TO RIGHT)  EXCEPT: COE MODELS/ 4700, 5800, 6900 SERIES AND 4 X SHOCK STEER AXLE	37301-3401 37301-3403 37301-3404 37301-3405 37301-3409 37301-3412 37390-4401 37390-4402 37390-4403 16-18831-000	HV2014	HV1014	HV514
*NOTE: SOME MODELS WITH BRAKE BOOSTERS FITTED TO THE REARWARD SIDE OF THE STEER AXLE INNER WHEEL HUB MAY HAVE CLEARANCE ISSUES WITH THIS SHOCK. IF THIS IS THE CASE, SHOCK HV2033 MUST BE USED (FITTED UPSIDE DOWN). PLEASE CHECK YOUR SPECIFIC APPLICATION.					
2008 -	ALL MODELS WITH: PARABOLIC/MULTILEAF  (LOWER STUD RUNNING FRONT TO BACK)  EXCEPT: COE MODELS/ 4700, 5800, 6900 SERIES AND 4 X SHOCK STEER AXLE	10-13809-000 10-14177-000	HV2008	HV1008	HV508
2014 -	5800/ 6900 SERIES	10-33809-000	HV2038		
2014-	4700 SERIES  (INCLUDING TWIN STEER)	10-13809-000 10-14177-000	HV2009	HV1008	HV1008



## SHOCK ABSORBER RANGE

YEAR	MODEL/ SUSPENSION TYPE	OME#	HV2000 SERIES	HV1000 SERIES	HV500 SERIES
<b>WESTERN STAR (CONTINUED)</b>					
<b>REAR SUSPENSION</b>					
N/A	NEWAY AD246/10 (WILL NOT FIT AD252)	90045132	HV2036L HV2036R	HV1008	
	HENDRICKSON PRIMAAX (8.5" & 10" OPTIONS)	60657-003 60657-003L 60657-005 98583-032	HV2010L HV2010R		
N/A	AIRLINER	16-15817-000 16-20649-000	HV2003L HV2003R	HV1003	HV503
	HENDRICKSON HAS-4 SERIES* EXCEPT INBOARD SHOCK OPTION	60670-005	HV2005		

*\*PLEASE ENSURE THERE IS MINIMUM 150mm HORIZONTAL CLEARANCE BETWEEN THE CENTRE OF THE LOWER EYEBOLT (ON THE REAR AXLE SHOCK) AND THE TAILLIGHT BAR. IF THERE IS INSUFFICIENT CLEARANCE, THE SHOCK SIDE CHAMBER MAY FOUL ON THE TAILLIGHT BAR.*

## TRAILER SHOCKS

### BPW

OM / OT SERIES	SHOCK MOUNTED STRAIGHT (LONG SHOCK)*	02-3702-1800	HV2019L HV2019R	HV1019	HV519
	SHOCK MOUNTED ON AN ANGLE (SHORT SHOCK)	02-3722-8300	HV2001		

*\*HV2000 SHOCK MUST BE FITTED UPSIDE DOWN TO ALLOW CLEARANCE FOR SIDE CHAMBER*

,

NOTE: HV20XXL = LEFT HAND SIDE, HV20XXR = RIGHT HAND SIDE



## HV2000 SERIES FULL SHOCK PACKAGES

Full shock package includes all steer and drive shocks and both front & rear air kits.

PART NUMBER	FRONT SHOCKS	REAR SHOCKS	AIRKITS
HV2500	2x - HV2011	4 x HV2021	1 x RR K001 1 x RR K002
HV2501	2x - HV2011	4 x HV2020	1 x RR K001 1 x RR K002
HV2502	2x - HV2011	2 x HV2004L 2 x HV2004R	1 x RR K001 1 x RR K002
HV2503	2x - HV2033	2 x HV2036L 2 x HV2036R	1 x RR K001 1 x RR K002
HV2504	2x - HV2033	2 x HV2004L 2 x HV2004R	1 x RR K001 1 x RR K002
HV2505	2x - HV2033	2 x HV2010L 2 x HV2010R	1 x RR K001 1 x RR K002
HV2506	2x - HV2008	2 x HV2036L 2 x HV2036R	1 x RR K001 1 x RR K002
HV2507	2x - HV2008	2 x HV2004L 2 x HV2004R	1 x RR K001 1 x RR K002
HV2508	2x - HV2008	2 x HV2010L 2 x HV2010R	1 x RR K001 1 x RR K002
HV2509	2x - HV2014	2 x HV2036L 2 x HV2036R	1x RR K001 1 x RR K002
HV2510	2x - HV2014	2 x HV2004L 2 x HV2004R	1 x-RR K001 1 x -RR K002
HV2511	2x - HV2014	2 x HV2010L 2 x HV2010R	1 x RR K001 1 x RR K002
HV2512	2x - HV2026	2 x HV2010L 2 x HV2010R	1 x RR K001 1 x RR K002
HV2513	2x - HV2026	4 x HV2005	1 x RR K001 1 x RR K002
HV2514	2x - HV2030	2 x HV2010L 2 x HV2010R	1 x RR K001 1 x RR K002
HV2515	2x - HV2030	4 x HV2005	1 x RR K001 1 x RR K002
HV2516	2x - HV2026	4 x HV2037	1 x RR K001 1 x RR K002
HV2517	2x HV2006	2 x HV2003L 2 x HV2003R	1 x RR K001 1 x RR K002



## CAB MOUNT SHOCKS

The RedRoo Cab series shock absorber is suitable for conventional cabs that have shocks between the chassis and the cabin. The RedRoo Cab Series is an adjustable monotube, providing fine tuning of the dampening pressures and ensuring a more comfortable ride. This can be optimized with the addition of a RedRoo Air installation kit.

YEAR	MODEL/TYPE	OME#	Part #
<b>KENWORTH</b>			
N/A	CONVENTIONAL SLEEPER CAB	1202-K064 1202-K065	CMS101
<b>FREIGHTLINER</b>			
N/A	DAYCAB	18-60764-000	CMS103
N/A	SLEEPER CAB	18-66113-00	CMS104
<b>MACK</b>			
N/A	TITAN SLEEPER CAB*	14QK399M2 25625635 25625636	CMS102
* SHOCK NEEDS TO BE INSTALLED UPSIDE DOWN. Panhard rod may need to be removed to allow for fitment of sleeper cab shocks. Air may also need to be drained from shock to allow easy compression of shocks prior to fitment.			
<b>WESTERN STAR</b>			
N/A	DAYCAB OEEQUIVELENT	67512940L 66010-3407	CMS105
N/A	SLEEPER CAB OE EQUIVELENT	18-60773-000 66010-3406	CMS106





## AIR INSTALLATION KITS

We recommend your new RedRoo shocks be connected to the air system of the heavy vehicle they are being installed in, wherever possible. Although this is not a requirement, RedRoo shocks provide superior results when connected to an air supply, in accordance with our guidelines.

PART NUMBER	KIT DESCRIPTION
RRK001	Air Installation Kit - Steer GENERIC
RRK002	Air Installation Kit - Drive Tandem Axle GENERIC
RRK008	Air Installation Kit - DENNIS EAGLE Steer
RRK009	Air Installation Kit - BPW Trailer
RRK010	Air Installation Kit - Heavy Duty Steer GENERIC
RRK011	Air Installation Kit - Heavy Duty Drive GENERIC
RRK012	Air Installation Kit - KENWORTH Twin Steer
RRK013	Air Installation Kit - KENWORTH Tridem Drive
RRK014	Air Installation Kit - MACK TITAN Steer
RRK015	Air Installation Kit - CAB SHOCKS KENWORTH
RRK016	Air Installation Kit - MACK TITAN Sleeper Cab
RRK017	Air Installation Kit - WESTERN STAR Sleeper Cab
RRK018	Air Installation Kit - AIRLINER DRIVE with 3/8" Air Supply

*\*PLEASE NOTE: RedRoo shocks come standard with a Schrader type valve fitted to the side chamber, and pre-pressurized to 50psi. In order to connect shock to the air system of the truck, these fittings must be removed and a suitable hose fitting, such as in these kits, must be installed.*

*WARNING: Ensure all air is drained from the side chamber before removing any fittings, otherwise serious injury may result. If in doubt, consult your dealer for advice.*

## CAB SHOCK BUSH KITS

PART NUMBER	KIT DESCRIPTION
RRCBUSHKIT101	Cab Shock Bush Kit for CMS101 *
RRCBUSHKIT102	Cab Shock Bush Kit for CMS102 *
RRCBUSHKIT103	Cab Shock Bush Kit for CMS103 *
RRCBUSHKIT104	Cab Shock Bush Kit for CMS104 *
RRCBUSHKIT105	Cab Shock Bush Kit for CMS105 *
RRCBUSHKIT106	Cab Shock Bush Kit for CMS106 *

*\*1 kit =2 cab shock, includes top and bottom bushes*



## SPARE PARTS

PART NUMBER	KIT DESCRIPTION
RRS004	Dust Boot Short – 270mm relaxed length
RRS005	Dust Boot Long – 320mm relaxed length
RRS001	Standard Eye Bush – 1-piece Polyurethane L48mm x ID25.4mm x OD48mm
RRS006	Big Eye Bush - 1-piece Polyurethane L55mm x ID30mm x OD50mm







## SHOCK ABSORBER BUSH KITS

PART NUMBER	DESCRIPTION	HV2000		
RRBBUSH001	Bonded Bush Kit	HV2001		
RRBBUSH002	Bonded Bush Kit	HV2003L	HV2030R	
RRBBUSH003	Bonded Bush Kit	HV2004L	HV2009	HV2031
		HV2004R	HV2014	HV2033
		HV2008	HV2022	HV2038
RRBBUSH004	Bonded Bush Kit	HV2005		
RRBBUSH005	Bonded Bush Kit	HV2006	HV2007	
RRBBUSH006	Bonded Bush Kit	HV2010L	HV2010R	
RRBBUSH007	Bonded Bush Kit	HV2011		
RRBBUSH008	Bonded Bush Kit	HV2016		
RRBBUSH009	Bonded Bush Kit	HV2025		
RRBBUSH010	Bonded Bush Kit	HV2024		
RRBBUSH011	Bonded Bush Kit	HV2026	HV2032	
RRBBUSH012	Bonded Bush Kit	HV2036L	HV2036R	HV2030
RRBBUSH013	Bonded Bush Kit	HV2037		
RRBBUSH014	Bonded Bush Kit	HV2002		
RRBBUSH015	Bonded Bush Kit	HV2019L	HV2019R	
RRSTUDKIT001	Bonded Bush Kit	HV2020	HV2021	
RRSTUDKIT002	Bonded Bush Kit	HV2029		
RRSTUDKIT003	Bonded Bush Kit	HV2034	HV2035	



SHOCK ABSORBER BUSH KITS cont

PART NUMBER	DESCRIPTION	HV1000	HV500
RRBBUSH001	Bonded Bush Kit		
RRBBUSH002	Bonded Bush Kit	HV1003L HV1003R	HV503
RRBBUSH003	Bonded Bush Kit	HV1008 HV1014	HV508 HV514
RRBBUSH004	Bonded Bush Kit		
RRBBUSH005	Bonded Bush Kit	HV1006	HV506
RRBBUSH006	Bonded Bush Kit		
RRBBUSH007	Bonded Bush Kit	HV1011	HV511
RRBBUSH008	Bonded Bush Kit	HV1016	
RRBBUSH009	Bonded Bush Kit		
RRBBUSH010	Bonded Bush Kit		
RRBBUSH011	Bonded Bush Kit	HV1026	HV526
RRBBUSH012	Bonded Bush Kit	HV1030	HV530
RRBBUSH013	Bonded Bush Kit		
RRBBUSH014	Bonded Bush Kit		
RRBBUSH015	Bonded Bush Kit	HV1019	HV519
RRSTUDKIT001	Bonded Bush Kit	HV1021	HV521
RRSTUDKIT002	Bonded Bush Kit		
RRSTUDKIT003	Bonded Bush Kit		

\*Bonded bush kits include top and bottom bushes to suit 1 x shock absorber



## SHOCK ABSORBER BUSHES

PART NUMBER	DESCRIPTION
RRS001	Standard Eye Bush – 1-piece Polyurethane L48mm x ID25.4mm x OD48mm
RRS006	Big Eye Bush - 1-piece Polyurethane L55mm x ID30mm x OD50mm
RRBUSH9301	Bonded Rubber Eye Bush & Sleeve ID16.2mm x L95mm
RRBUSH9302	Bonded Rubber Eye Bush & Sleeve ID19.2mm x L48.5mm
RRBUSH9303	Bonded Rubber Eye Bush & Sleeve ID16.2mm x L48.5mm
RRBUSH9305	Bonded Rubber Eye Bush & Sleeve ID19.2mm x L56mm
RRBUSH9306	Bonded Rubber Eye Bush & Sleeve ID19.2mm x L80.5mm
RRBUSH9307	Bonded Rubber Eye Bush & Sleeve ID19.2mm x L96mm
RRBUSH9311	Bonded Rubber Eye Bush & Sleeve ID16.2mm x L64.5mm
RRBUSH9312	Bonded Rubber Eye Bush & Sleeve ID16.2mm x L98.5mm
RRBUSH9318	Bonded Rubber Eye Bush & Sleeve ID19.2mm x L42mm
RRBUSH9322	Bonded Rubber Eye Bush & Sleeve ID20.2mm x L42mm



## INDIVIDUAL SLEEVES

Individual sleeves are available in the below sizes. Please quote the part number listed next to the sleeve required. Note all sleeves have a standard od of 25.4mm to suit the RedRoo RRS001 polyurethane bush, unless otherwise specified.

PART NUMBER	ID mm	Length mm
RRSLEEVE-01	16.2mm	95mm
RRSLEEVE-02	19.2mm	48.5mm
RRSLEEVE-03	16.2mm	48.5mm
RRSLEEVE-04	16.2mm	49.5mm
RRSLEEVE-05	19.2mm	56mm
RRSLEEVE-06	19.2mm	80.5mm
RRSLEEVE-07	19.2mm	96mm
RRSLEEVE-08	19.2mm	45mm
RRSLEEVE-09	19.2mm	50mm
RRSLEEVE-10	24.9 x 300Dmm	50mm
RRSLEEVE-11	16.2mm	64.5mm
RRSLEEVE-12	16.2mm	98.5mm
RRSLEEVE-15	25.6 x 350Dmm	21mm
RRSLEEVE-17	25.6 x 350Dmm	6mm
RRSLEEVE-18	19.2mm	42mm
RRSLEEVE-19	12.9mm	48.5mm
RRSLEEVE-20	19.2 x 300Dmm	8mm
RRSLEEVE-21	20mm	48.5mm
RRSLEEVE-22	20.2mm	42mm
RRSLEEVE-23	12mm	48.5mm
RRS001*	Standard Eye Bush – 1-piece Polyurethane L48mm x ID25.4mm x OD48mm	
RRS006*	Big Eye Bush - 1-piece Polyurethane L55mm x ID30mm x OD50mm	

*\*Replacement bushes used to suit the above sleeves*

*Copyright © 2016  
RedRoo Shocks*

Last revised – June 3, 2019

REDROO SHOCKS  
2 Merrindale Drive  
Victoria, Australia 3136

Telephone +61 3 9751 7999  
[info@redrooshocks.com.au](mailto:info@redrooshocks.com.au)  
[www.redrooshocks.com.au](http://www.redrooshocks.com.au)

